

HP Printers at End of Support

Model Name	Support Level
HP 2000c Printer	End of Support
HP 2000cn Printer	End of Support
HP 2000cse Printer	End of Support
HP 2000cxi Printer	End of Support
HP 2500c Plus Printer	End of Support
HP 2500c Printer	End of Support
HP 2500cm Printer	End of Support
HP 2500cse Printer	End of Support
HP 2500cxi Printer	End of Support
HP 910 Printer	Partial
HP 915 Inkjet All-in-One	Partial
HP Business Inkjet 1000 Printer	End of Support
HP Business Inkjet 1100 Printer	End of Support
HP Business Inkjet 1100d Printer	End of Support
HP Business Inkjet 1100dtn Printer	End of Support
HP Business Inkjet 1200 Printer	End of Support
HP Business Inkjet 1200d Printer	End of Support
HP Business Inkjet 1200dn Printer	End of Support
HP Business Inkjet 1200dtn Printer	End of Support
HP Business Inkjet 1200dtwn Printer	End of Support
HP Business Inkjet 2200 Printer	End of Support
HP Business Inkjet 2200se Printer	End of Support
HP Business Inkjet 2200xi Printer	End of Support
HP Business Inkjet 2230 Printer	End of Support
HP Business Inkjet 2250 Printer	End of Support
HP Business Inkjet 2250tn Printer	End of Support
HP Business Inkjet 2300 Printer	End of Support
HP Business Inkjet 2300dtn Printer	End of Support
HP Business Inkjet 2300n Printer	End of Support
HP Business Inkjet 2600 Printer	End of Support
HP Business Inkjet 2600dn Printer	End of Support
HP Business Inkjet 3000 Printer	End of Support
HP Business Inkjet 3000dtn Printer	End of Support
HP Business Inkjet 3000n Printer	End of Support
HP Color Inkjet cp1160 Printer	End of Support
HP Color Inkjet cp1160tn Printer	End of Support
HP Color Inkjet cp1700 Printer	End of Support
HP Color Inkjet cp1700d Printer	End of Support
HP Color Inkjet cp1700ps Printer	End of Support
HP Color LaserJet 1600 Printer	End of Support
HP Color LaserJet 2500 Printer	End of Support
HP Color LaserJet 2500I Printer	End of Support
HP Color LaserJet 2500Ise Printer	End of Support
HP Color LaserJet 2500n Printer	End of Support
HP Color LaserJet 2500tn Printer	End of Support
HP Color LaserJet 2550 Printer	End of Support
HP Color LaserJet 2550I Printer	End of Support
HP Color LaserJet 2550In Printer	End of Support
HP Color LaserJet 2550n Printer	End of Support
HP Color LaserJet 2600n Printer	End of Support
HP Color LaserJet 2605 Printer	End of Support

	Model Name	Support Level
	HP Color LaserJet 2605dn Printer	End of Support
	HP Color LaserJet 2605dn Xi Printer	End of Support
	HP Color LaserJet 2605dtn Printer	End of Support
	HP Color LaserJet 2700 Printer	End of Support
	HP Color LaserJet 2700n Printer	End of Support
	HP Color LaserJet 2800 All-in-one	End of Support
	HP Color LaserJet 2820 All-in-one	End of Support
	HP Color LaserJet 2830 All-in-one	End of Support
	HP Color LaserJet 2840 All-in-one	End of Support
	HP Color LaserJet 3500n Printer	End of Support
	HP Color LaserJet 3550n Printer	End of Support
	HP Color LaserJet 3700 Printer	End of Support
	HP Color LaserJet 3700d Printer	End of Support
	HP Color LaserJet 3700dn Printer	End of Support
	HP Color LaserJet 3700dtn Printer	End of Support
	HP Color LaserJet 3700n Printer	End of Support
	HP Color LaserJet 3800 Printer	End of Support
	HP Color LaserJet 3800dn Printer	End of Support
	HP Color LaserJet 3800dtn Printer	End of Support
	HP Color LaserJet 3800n Printer	End of Support
	HP Color LaserJet 4500 Printer	End of Support
	HP Color LaserJet 4500dn Printer	End of Support
	HP Color LaserJet 4500n Printer	End of Support
	HP Color LaserJet 4550 Printer	End of Support
	HP Color LaserJet 4550dn Printer	End of Support
	HP Color LaserJet 4550hdn Plus Printer	End of Support
	HP Color LaserJet 4550hdn Printer	End of Support
	HP Color LaserJet 4550n Plus Printer	End of Support
	HP Color LaserJet 4550n Printer	End of Support
	HP Color LaserJet 4600 Printer	End of Support
	HP Color LaserJet 4600 Series Printer	End of Support
	HP Color LaserJet 4600dn Printer	End of Support
	HP Color LaserJet 4600dtn Printer	End of Support
	HP Color LaserJet 4600hdn Printer	End of Support
	HP Color LaserJet 4600n Printer	End of Support
	HP Color LaserJet 4610n Printer	End of Support
	HP Color LaserJet 4650 Printer	End of Support
	HP Color LaserJet 4650dn Printer	End of Support
	HP Color LaserJet 4650dtn Printer	End of Support
	HP Color LaserJet 4650hdn Printer	End of Support
	HP Color LaserJet 4650n Printer	End of Support
	HP Color LaserJet 4730 MFP	End of Support
	HP Color LaserJet 4730x MFP	End of Support
	HP Color LaserJet 4730xm MFP	End of Support
	HP Color LaserJet 4730xs MFP	End of Support
	HP Color LaserJet 5 Printer	End of Support
	HP Color LaserJet 5500 Printer	End of Support
	HP Color LaserJet 5500dn Printer	End of Support
	HP Color LaserJet 5500dtn Printer	End of Support
	HP Color LaserJet 5500hdn Printer	End of Support
	HP Color LaserJet 5500n Printer	End of Support
	HP Color LaserJet 5m Printer	End of Support

Model Name	Support Level
HP Color LaserJet cm1015 MFP	End of Support
HP Color LaserJet cm1017 MFP	End of Support
HP Color LaserJet cm2320 MFP	End of Support
HP Color LaserJet cm4540 MFP	Partial
HP Color LaserJet cm4730 MFP	Partial
HP Color LaserJet cm4730f MFP	Partial
HP Color LaserJet cm4730fm MFP	Partial
HP Color LaserJet cm4730fsk MFP	Partial
HP Color LaserJet cm6049 MFP	End of Support
HP Designjet 4500mfp	Partial
HP Designjet 4520mfp	Partial
HP Deskjet 1100c Printer	End of Support
HP Deskjet 1120c Printer	End of Support
HP Deskjet 1120cse Printer	End of Support
HP Deskjet 1120cxi Printer	End of Support
HP Deskjet 1125c Printer	End of Support
HP Deskjet 1200c/ps Printer	End of Support
HP Deskjet 1220c Printer	End of Support
HP Deskjet 1220c/ps Printer	End of Support
HP Deskjet 1220cse Printer	End of Support
HP Deskjet 1220cxi Printer	End of Support
HP Deskjet 1280 Printer	End of Support
HP Deskjet 1600c Printer	End of Support
HP Deskjet 1600cm Printer	End of Support
HP Deskjet 1600cn Printer	End of Support
HP Deskjet 2510 All-in-One	End of Support
HP Deskjet 2511 All-in-One	End of Support
HP Deskjet 2512 All-in-One	End of Support
HP Deskjet 2514 All-in-One	End of Support
HP Deskjet 3050 j610 Series	End of Support
HP Deskjet 3320 Color Inkjet Printer	Partial
HP Deskjet 3320v Color Inkjet Printer	Partial
HP Deskjet 3322 Color Inkjet Printer	Partial
HP Deskjet 3323 Color Inkjet Printer	Partial
HP Deskjet 3325 Printer/scanjet 3530c	End of Support
HP Deskjet 3420 Color Inkjet Printer	Partial
HP Deskjet 3420v Color Inkjet Printer	Partial
HP Deskjet 3425 Printer	End of Support
HP Deskjet 3450 Color Inkjet Printer	Partial
HP Deskjet 3500 Color Inkjet Printer	Partial
HP Deskjet 350c Printer	End of Support
HP Deskjet 350cbi Printer	End of Support
HP Deskjet 3510 E-all-in-one	End of Support
HP Deskjet 3511 E-all-in-one	End of Support
HP Deskjet 3512 E-all-in-one	End of Support
HP Deskjet 3520 Color Inkjet Printer	Partial
HP Deskjet 3520v Color Inkjet Printer	Partial
HP Deskjet 3520w Color Inkjet Printer	Partial
HP Deskjet 3535 Color Inkjet Printer	Partial
HP Deskjet 3538 Color Inkjet Printer	Partial
HP Deskjet 3550 Color Inkjet Printer	Partial
HP Deskjet 3550v Color Inkjet Printer	Partial

	Model Name	Support Level
	HP Deskjet 3550w Color Inkjet Printer	Partial
	HP Deskjet 3558 Color Inkjet Printer	Partial
	HP Deskjet 3600 Color Inkjet Printer	End of Support
	HP Deskjet 3620 Color Inkjet Printer	Partial
	HP Deskjet 3645 Color Inkjet Printer	Partial
	HP Deskjet 3647 Color Inkjet Printer	Partial
	HP Deskjet 3650 Color Inkjet Printer	Partial
	HP Deskjet 3651 Color Inkjet Printer	Partial
	HP Deskjet 3652 Color Inkjet Printer	Partial
	HP Deskjet 3653 Color Inkjet Printer	Partial
	HP Deskjet 3658 Color Inkjet Printer	Partial
	HP Deskjet 3668 Color Inkjet Printer	Partial
	HP Deskjet 3740 Color Inkjet Printer	Partial
	HP Deskjet 3743 Color Inkjet Printer	Partial
	HP Deskjet 3744 Color Inkjet Printer	Partial
	HP Deskjet 3745 Color Inkjet Printer	Partial
	HP Deskjet 3745v Color Inkjet Printer	Partial
	HP Deskjet 3747 Color Inkjet Printer	Partial
	HP Deskjet 3748 Color Inkjet Printer	Partial
	HP Deskjet 3810 Color Inkjet Printer	End of Support
	HP Deskjet 3816 Color Inkjet Printer	End of Support
	HP Deskjet 3818 Color Inkjet Printer	End of Support
	HP Deskjet 3819 Color Inkjet Printer	End of Support
	HP Deskjet 3822 Color Inkjet Printer	End of Support
	HP Deskjet 3843 Color Inkjet Printer	Partial
	HP Deskjet 3844 Color Inkjet Printer	Partial
	HP Deskjet 3845 Color Inkjet Printer	Partial
	HP Deskjet 3845xi Color Inkjet Printer	Partial
	HP Deskjet 3847 Color Inkjet Printer	Partial
	HP Deskjet 3848 Color Inkjet Printer	Partial
	HP Deskjet 3870 Color Inkjet Printer	End of Support
	HP Deskjet 3900 Color Inkjet Printer	End of Support
	HP Deskjet 3910 Color Inkjet Printer	Partial
	HP Deskjet 3915 Color Inkjet Printer	Partial
	HP Deskjet 3918 Color Inkjet Printer	Partial
	HP Deskjet 3920 Color Inkjet Printer	Partial
	HP Deskjet 3930 Color Inkjet Printer	Partial
	HP Deskjet 3930v Color Inkjet Printer	Partial
	HP Deskjet 3938 Color Inkjet Printer	Partial
	HP Deskjet 3940 Color Inkjet Printer	Partial
	HP Deskjet 3940v Color Inkjet Printer	Partial
	HP Deskjet 450cbi Mobile Printer	End of Support
	HP Deskjet 450ci Mobile Printer	End of Support
	HP Deskjet 450wbt Mobile Printer	End of Support
	HP Deskjet 460c Mobile Printer	End of Support
	HP Deskjet 460cb Mobile Printer	End of Support
	HP Deskjet 460wbt Mobile Printer	End of Support
	HP Deskjet 460wf Mobile Printer	End of Support
	HP Deskjet 500 Printer	End of Support
	HP Deskjet 500c Printer	End of Support
	HP Deskjet 500j Printer	End of Support
	HP Deskjet 500k Printer	End of Support

	Model Name	Support Level
	HP Deskjet 500q Printer	End of Support
	HP Deskjet 505j Printer	End of Support
	HP Deskjet 510 Printer	End of Support
	HP Deskjet 520 Printer	End of Support
	HP Deskjet 540 Printer	End of Support
	HP Deskjet 550c Printer	End of Support
	HP Deskjet 5552 Color Inkjet Printer	End of Support
	HP Deskjet 5600 Color Inkjet Printer	End of Support
	HP Deskjet 5650 Color Inkjet Printer	End of Support
	HP Deskjet 5650v Color Inkjet Printer	End of Support
	HP Deskjet 5650w Color Inkjet Printer	End of Support
	HP Deskjet 5655 Color Inkjet Printer	End of Support
	HP Deskjet 5800 Color Inkjet Printer	End of Support
	HP Deskjet 5850 Color Inkjet Printer	End of Support
	HP Deskjet 5850w Color Inkjet Printer	End of Support
	HP Deskjet 600 Printer	End of Support
	HP Deskjet 600c Printer	End of Support
	HP Deskjet 600k Printer	End of Support
	HP Deskjet 610c Printer	End of Support
	HP Deskjet 610cl Printer	End of Support
	HP Deskjet 6120 Color Inkjet Printer	End of Support
	HP Deskjet 612c Printer	End of Support
	HP Deskjet 630c Printer	End of Support
	HP Deskjet 632c Printer	End of Support
	HP Deskjet 648c Printer	End of Support
	HP Deskjet 660c Printer	End of Support
	HP Deskjet 660cse Printer	End of Support
	HP Deskjet 660k Printer	End of Support
	HP Deskjet 670c	End of Support
	HP Deskjet 670c Printer	End of Support
	HP Deskjet 670k Printer	End of Support
	HP Deskjet 670tv Printer	End of Support
	HP Deskjet 672c Printer	End of Support
	HP Deskjet 680c Printer	End of Support
	HP Deskjet 682c Printer	End of Support
	HP Deskjet 690c Plus Printer	End of Support
	HP Deskjet 690c Printer	End of Support
	HP Deskjet 692c Printer	End of Support
	HP Deskjet 692k Printer	End of Support
	HP Deskjet 693c Printer	End of Support
	HP Deskjet 694c Printer	End of Support
	HP Deskjet 695c Printer	End of Support
	HP Deskjet 695cci Printer	End of Support
	HP Deskjet 697c Printer	End of Support
	HP Deskjet 810c Printer	End of Support
	HP Deskjet 812c Printer	End of Support
	HP Deskjet 825c Printer	End of Support
	HP Deskjet 825cvr Printer	End of Support
	HP Deskjet 841c Printer	End of Support
	HP Deskjet 843c Printer	End of Support
	HP Deskjet 843cxe Printer	End of Support
	HP Deskjet 855c Printer	End of Support

	Model Name	Support Level
	HP Deskjet 855cse Printer	End of Support
	HP Deskjet 855cxi Printer	End of Support
	HP Deskjet 870c Printer	End of Support
	HP Deskjet 870cse Printer	End of Support
	HP Deskjet 870cxi Printer	End of Support
	HP Deskjet 870k Printer	End of Support
	HP Deskjet 880c Printer	End of Support
	HP Deskjet 882c Printer	End of Support
	HP Deskjet 890c Printer	End of Support
	HP Deskjet 890cse Printer	End of Support
	HP Deskjet 895c Printer	End of Support
	HP Deskjet 895cse Printer	End of Support
	HP Deskjet 895cxi Printer	End of Support
	HP Deskjet 916c Printer	End of Support
	HP Deskjet 952c Printer	End of Support
	HP Deskjet 957c Printer	End of Support
	HP Deskjet 959c Printer	End of Support
	HP Deskjet 960c Printer	End of Support
	HP Deskjet 960cse Printer	End of Support
	HP Deskjet 960cxi Printer	End of Support
	HP Deskjet 970c Printer	End of Support
	HP Deskjet 970cse Printer	End of Support
	HP Deskjet 970cxi Printer	End of Support
	HP Deskjet 975c Printer	End of Support
	HP Deskjet 975cse Printer	End of Support
	HP Deskjet 975cxi Printer	End of Support
	HP Deskjet 980c Printer	End of Support
	HP Deskjet 980cxi Printer	End of Support
	HP Deskjet 995c Printer	End of Support
	HP Deskjet 995ck Printer	End of Support
	HP Deskjet d1311 Printer	Partial
	HP Deskjet d1320 Printer	Partial
	HP Deskjet d1330 Printer	Partial
	HP Deskjet d1341 Printer	Partial
	HP Deskjet d1360 Printer	Partial
	HP Deskjet d1368 Printer	Partial
	HP Deskjet d1415 Printer	Partial
	HP Deskjet d1420 Printer	Partial
	HP Deskjet d1430 Printer	Partial
	HP Deskjet d1445 Printer	Partial
	HP Deskjet d1455 Printer	Partial
	HP Deskjet d1460 Printer	Partial
	HP Deskjet d1468 Printer	Partial
	HP Deskjet d1470 Printer	Partial
	HP Deskjet d1520 Printer	Partial
	HP Deskjet d1530 Printer	Partial
	HP Deskjet d1550 Printer	Partial
	HP Deskjet d1555 Printer	Partial
	HP Deskjet d1558 Printer	Partial
	HP Deskjet d1560 Printer	Partial
	HP Deskjet d1568 Printer	Partial
	HP Deskjet d2320 Printer	Partial

	Model Name	Support Level
	HP Deskjet d2330 Printer	Partial
	HP Deskjet d2345 Printer	Partial
	HP Deskjet d2360 Printer	Partial
	HP Deskjet d2368 Printer	Partial
	HP Deskjet d2430 Printer	Partial
	HP Deskjet d2445 Printer	Partial
	HP Deskjet d2460 Printer	Partial
	HP Deskjet d2466 Printer	Partial
	HP Deskjet d2468 Printer	Partial
	HP Deskjet d4145 Printer	Partial
	HP Deskjet d4155 Printer	Partial
	HP Deskjet d4160 Printer	Partial
	HP Deskjet d4163 Printer	Partial
	HP Deskjet d4168 Printer	Partial
	HP Deskjet d4245 Printer	Partial
	HP Deskjet d4260 Printer	Partial
	HP Deskjet d4263 Printer	Partial
	HP Deskjet d4266 Printer	Partial
	HP Deskjet d4268 Printer	Partial
	HP Deskjet d4360 Printer	Partial
	HP Deskjet d4363 Printer	Partial
	HP Deskjet d4368 Printer	Partial
	HP Deskjet f2110 All-in-One	Partial
	HP Deskjet f2120 All-in-One	Partial
	HP Deskjet f2128 All-in-One	Partial
	HP Deskjet f2140 All-in-One	Partial
	HP Deskjet f2179 All-in-One	Partial
	HP Deskjet f2180 All-in-One	Partial
	HP Deskjet f2185 All-in-One	Partial
	HP Deskjet f2187 All-in-One	Partial
	HP Deskjet f2188 All-in-One	Partial
	HP Deskjet f2210 All-in-One	Partial
	HP Deskjet f2212 All-in-One	Partial
	HP Deskjet f2214 All-in-One	Partial
	HP Deskjet f2224 All-in-One	Partial
	HP Deskjet f2235 All-in-One	Partial
	HP Deskjet f2238 All-in-One	Partial
	HP Deskjet f2240 All-in-One	Partial
	HP Deskjet f2250 All-in-One	Partial
	HP Deskjet f2275 All-in-One	Partial
	HP Deskjet f2276 All-in-One	Partial
	HP Deskjet f2280 All-in-One	Partial
	HP Deskjet f2288 All-in-One	Partial
	HP Deskjet f2290 All-in-One	Partial
	HP Deskjet f310 All-in-One	Partial
	HP Deskjet f325 All-in-One	Partial
	HP Deskjet f335 All-in-One	Partial
	HP Deskjet f340 All-in-One	Partial
	HP Deskjet f350 All-in-One	Partial
	HP Deskjet f370 All-in-One	Partial
	HP Deskjet f375 All-in-One	Partial
	HP Deskjet f378 All-in-One	Partial

	Model Name	Support Level
	HP Deskjet f379 All-in-One	Partial
	HP Deskjet f380 All-in-One	Partial
	HP Deskjet f385 All-in-One	Partial
	HP Deskjet f388 All-in-One	Partial
	HP Deskjet f390 All-in-One	Partial
	HP Deskjet f394 All-in-One	Partial
	HP Deskjet f4135 All-in-One	Partial
	HP Deskjet f4140 All-in-One	Partial
	HP Deskjet f4150 All-in-One	Partial
	HP Deskjet f4172 All-in-One	Partial
	HP Deskjet f4175 All-in-One	Partial
	HP Deskjet f4180 All-in-One	Partial
	HP Deskjet f4185 All-in-One	Partial
	HP Deskjet f4188 All-in-One	Partial
	HP Deskjet f4190 All-in-One	Partial
	HP Deskjet f4194 All-in-One	Partial
	HP Deskjet Ink Advantage 2510 All-in-one	End of Support
	HP Deskjet Ink Advantage 2515 All-in-One	End of Support
	HP Deskjet Ink Advantage 2516 All-in-One	End of Support
	HP Deskjet Ink Advantage 3515 E-all-in-one	End of Support
	HP Deskjet Ink Advantage 3516 E-all-in-one	End of Support
	HP LaserJet 1000 Printer	End of Support
	HP LaserJet 1005 Printer	End of Support
	HP LaserJet 1010 Printer	End of Support
	HP LaserJet 1015 Printer	End of Support
	HP LaserJet 1022 Printer	End of Support
	HP LaserJet 1022nw Printer	End of Support
	HP LaserJet 1100 Printer	End of Support
	HP LaserJet 1100a All-in-One	End of Support
	HP LaserJet 1100a Se All-in-One	End of Support
	HP LaserJet 1100a Xi All-in-One	End of Support
	HP LaserJet 1100se Printer	End of Support
	HP LaserJet 1100xi Printer	End of Support
	HP LaserJet 1150 Printer	End of Support
	HP LaserJet 1200n Printer	End of Support
	HP LaserJet 1220 All-in-One	End of Support
	HP LaserJet 1220se All-in-One	End of Support
	HP LaserJet 1300 Printer	End of Support
	HP LaserJet 1300t Printer	End of Support
	HP LaserJet 1300xi Printer	End of Support
	HP LaserJet 1320 Printer	End of Support
	HP LaserJet 1320 Series Printer	End of Support
	HP LaserJet 1320nw Printer	End of Support
	HP LaserJet 1320t Printer	End of Support
	HP LaserJet 1320tn Printer	End of Support
	HP LaserJet 2100 Printer	End of Support
	HP LaserJet 2100 Series Printer	End of Support
	HP LaserJet 2100m Printer	End of Support
	HP LaserJet 2100se Printer	End of Support
	HP LaserJet 2100tn Printer	End of Support
	HP LaserJet 2100xi Printer	End of Support
	HP LaserJet 2200 Series Printer	End of Support

	Model Name	Support Level
	HP LaserJet 2300 Printer	End of Support
	HP LaserJet 2300 Series Printer	End of Support
	HP LaserJet 2300d Printer	End of Support
	HP LaserJet 2300dn Printer	End of Support
	HP LaserJet 2300dtn Printer	End of Support
	HP LaserJet 2300I Printer	End of Support
	HP LaserJet 2300n Printer	End of Support
	HP LaserJet 2410 Printer	End of Support
	HP LaserJet 2420 Printer	End of Support
	HP LaserJet 2420d Printer	End of Support
	HP LaserJet 2420dn Printer	End of Support
	HP LaserJet 2420n Printer	End of Support
	HP LaserJet 2430 Printer	End of Support
	HP LaserJet 2430dtn Printer	End of Support
	HP LaserJet 2430n Printer	End of Support
	HP LaserJet 2430t Printer	End of Support
	HP LaserJet 2430tn Printer	End of Support
	HP LaserJet 3020 All-in-One	End of Support
	HP LaserJet 3030 All-in-One	End of Support
	HP LaserJet 3052 All-in-One	End of Support
	HP LaserJet 3100 All-in-One	End of Support
	HP LaserJet 3100se All-in-One	End of Support
	HP LaserJet 3100xi All-in-One	End of Support
	HP LaserJet 3150 All-in-One	End of Support
	HP LaserJet 3150se All-in-One	End of Support
	HP LaserJet 3150xi All-in-One	End of Support
	HP LaserJet 3200 All-in-One	End of Support
	HP LaserJet 3200m All-in-One	End of Support
	HP LaserJet 3300 MFP	End of Support
	HP LaserJet 3310 Digital Printer Copier	End of Support
	HP LaserJet 3320 MFP	End of Support
	HP LaserJet 3320n MFP	End of Support
	HP LaserJet 3330 MFP	End of Support
	HP LaserJet 3380 All-in-One	End of Support
	HP LaserJet 3392 All-in-One	End of Support
	HP LaserJet 4 Plus Printer	End of Support
	HP LaserJet 4000 Printer	End of Support
	HP LaserJet 4000n Printer	End of Support
	HP LaserJet 4000se Printer	End of Support
	HP LaserJet 4000t Printer	End of Support
	HP LaserJet 4000tn Printer	End of Support
	HP LaserJet 4050 Printer	End of Support
	HP LaserJet 4050n Printer	End of Support
	HP LaserJet 4050se Printer	End of Support
	HP LaserJet 4050t Printer	End of Support
	HP LaserJet 4050tn Printer	End of Support
	HP LaserJet 4100 MFP	End of Support
	HP LaserJet 4101 MFP	End of Support
	HP LaserJet 4150 Printer	End of Support
	HP LaserJet 4200 Printer	End of Support
	HP LaserJet 4200dtn Printer	End of Support
	HP LaserJet 4200dtns Printer	End of Support

	Model Name	Support Level
	HP LaserJet 4200dtnsl Printer	End of Support
	HP LaserJet 4200l Printer	End of Support
	HP LaserJet 4200ln Printer	End of Support
	HP LaserJet 4200lvn Printer	End of Support
	HP LaserJet 4200n Printer	End of Support
	HP LaserJet 4200tn Printer	End of Support
	HP LaserJet 4240 Printer	End of Support
	HP LaserJet 4240n Printer	End of Support
	HP LaserJet 4300 Printer	End of Support
	HP LaserJet 4300dtn Printer	End of Support
	HP LaserJet 4300dtns Printer	End of Support
	HP LaserJet 4300dtnsl Printer	End of Support
	HP LaserJet 4300n Printer	End of Support
	HP LaserJet 4300tn Printer	End of Support
	HP LaserJet 4345 MFP	Partial
	HP LaserJet 4345x MFP	Partial
	HP LaserJet 4345xm MFP	Partial
	HP LaserJet 4345xs MFP	Partial
	HP LaserJet 4l Printer	End of Support
	HP LaserJet 4l Pro Printer	End of Support
	HP LaserJet 4lc Printer	End of Support
	HP LaserJet 4m Plus Printer	End of Support
	HP LaserJet 4ml Printer	End of Support
	HP LaserJet 4mp Printer	End of Support
	HP LaserJet 4si Mx Printer	End of Support
	HP LaserJet 4si Printer	End of Support
	HP LaserJet 4v Printer	End of Support
	HP LaserJet 5100 Printer	End of Support
	HP LaserJet 5100dtn Printer	End of Support
	HP LaserJet 5100le Printer	End of Support
	HP LaserJet 5100se Printer	End of Support
	HP LaserJet 5100tn Printer	End of Support
	HP LaserJet 5200l Printer	End of Support
	HP LaserJet 5200lx Printer	End of Support
	HP LaserJet 5l Printer	End of Support
	HP LaserJet 5l Xtra Printer	End of Support
	HP LaserJet 5l-fs Printer	End of Support
	HP LaserJet 5mp Printer	End of Support
	HP LaserJet 5p Printer	End of Support
	HP LaserJet 5si Hm Printer	End of Support
	HP LaserJet 5si Mopier	End of Support
	HP LaserJet 5si Mopier Engine	End of Support
	HP LaserJet 5si Mx Printer	End of Support
	HP LaserJet 5si Nx Printer	End of Support
	HP LaserJet 5si Printer	End of Support
	HP LaserJet 6l Gold Printer	End of Support
	HP LaserJet 6l Printer	End of Support
	HP LaserJet 6l Pro Printer	End of Support
	HP LaserJet 6lse Printer	End of Support
	HP LaserJet 6lxi Printer	End of Support
	HP LaserJet 6mp Printer	End of Support
	HP LaserJet 6mp Se Printer	End of Support

	Model Name	Support Level
	HP LaserJet 6mp Xi Printer	End of Support
	HP LaserJet 6p Printer	End of Support
	HP LaserJet m1522 MFP	End of Support
	HP LaserJet m1536dnf MFP	End of Support
	HP LaserJet m1537dnf MFP	End of Support
	HP LaserJet m1538dnf MFP	End of Support
	HP LaserJet m1539dnf MFP	End of Support
	HP LaserJet m3035 MFP	Partial
	HP LaserJet m3035xs MFP	Partial
	HP LaserJet m4345 MFP	Partial
	HP LaserJet m4345x MFP	Partial
	HP LaserJet m4345xm MFP	Partial
	HP LaserJet m4345xs MFP	Partial
	HP LaserJet m4349 MFP	Partial
	HP LaserJet m4555 MFP	Partial
	HP LaserJet m5035 MFP	Partial
	HP LaserJet m5035x MFP	Partial
	HP LaserJet m5035xs MFP	Partial
	HP LaserJet m5039 MFP	Partial
	HP LaserJet p2014 Printer	End of Support
	HP LaserJet p2014n Printer	End of Support
	HP LaserJet p2015 Printer	End of Support
	HP LaserJet p2015d Printer	End of Support
	HP LaserJet p2015dn Printer	End of Support
	HP LaserJet p2015n Printer	End of Support
	HP LaserJet p2015x Printer	End of Support
	HP LaserJet p3004 Printer	End of Support
	HP LaserJet p4515 Printer	End of Support
	HP Mopier 240 Printer	End of Support
	HP Mopier 320 Printer	End of Support
	HP Officejet 300 All-in-One	End of Support
	HP Officejet 310 All-in-one Series Printer	End of Support
	HP Officejet 320 All-in-one Series Printer	End of Support
	HP Officejet 330 All-in-One	End of Support
	HP Officejet 350 All-in-One	End of Support
	HP Officejet 4100 Series All-in-One	End of Support
	HP Officejet 4105 All-in-One	End of Support
	HP Officejet 4110 All-in-One	End of Support
	HP Officejet 4110v All-in-One	End of Support
	HP Officejet 4110xi All-in-One	End of Support
	HP Officejet 4115 All-in-One	End of Support
	HP Officejet 4200 All-in-One	Partial
	HP Officejet 4211 All-in-One	Partial
	HP Officejet 4212 All-in-One	Partial
	HP Officejet 4215 All-in-One	Partial
	HP Officejet 4215v All-in-One	Partial
	HP Officejet 4215xi All-in-One	Partial
	HP Officejet 4219 All-in-One	Partial
	HP Officejet 4251 All-in-One	Partial
	HP Officejet 4252 All-in-One	Partial
	HP Officejet 4255 All-in-One	Partial
	HP Officejet 4256 All-in-One	Partial

	Model Name	Support Level
	HP Officejet 4259 All-in-One	Partial
	HP Officejet 4308 All-in-One	Partial
	HP Officejet 4311 All-in-One	Partial
	HP Officejet 4312 All-in-One	Partial
	HP Officejet 4314 All-in-One	Partial
	HP Officejet 4315 All-in-One	Partial
	HP Officejet 4315v All-in-One	Partial
	HP Officejet 4315xi All-in-One	Partial
	HP Officejet 4317 All-in-One	Partial
	HP Officejet 4319 All-in-One	Partial
	HP Officejet 4338 All-in-One	Partial
	HP Officejet 4352 All-in-One	Partial
	HP Officejet 4353 All-in-One	Partial
	HP Officejet 4355 All-in-One	Partial
	HP Officejet 4357 All-in-One	Partial
	HP Officejet 4359 All-in-One	Partial
	HP Officejet 4500 g510n-z All-in-One	End of Support
	HP Officejet 5100 All-in-One	End of Support
	HP Officejet 5105 All-in-One	End of Support
	HP Officejet 5110 All-in-One	End of Support
	HP Officejet 5110v All-in-One	End of Support
	HP Officejet 5110xi All-in-One	End of Support
	HP Officejet 520 All-in-One	End of Support
	HP Officejet 5505 All-in-One	Partial
	HP Officejet 5508 All-in-One	Partial
	HP Officejet 5510 All-in-One	Partial
	HP Officejet 5510v All-in-One	Partial
	HP Officejet 5510xi All-in-One	Partial
	HP Officejet 5515 All-in-One	Partial
	HP Officejet 5600 Series All-in-One	Partial
	HP Officejet 5605 All-in-One	Partial
	HP Officejet 5607 All-in-One	Partial
	HP Officejet 5608 All-in-One	Partial
	HP Officejet 5609 All-in-One	Partial
	HP Officejet 5610 All-in-One	Partial
	HP Officejet 5610v All-in-One	Partial
	HP Officejet 5610xi All-in-One	Partial
	HP Officejet 5615 All-in-One	Partial
	HP Officejet 5679 All-in-One	Partial
	HP Officejet 5680 All-in-One	Partial
	HP Officejet 570 All-in-One	End of Support
	HP Officejet 580 All-in-One	End of Support
	HP Officejet 590 All-in-One	End of Support
	HP Officejet 600 All-in-One	End of Support
	HP Officejet 610 All-in-One	End of Support
	HP Officejet 6150 All-in-One	End of Support
	HP Officejet 630 All-in-One	End of Support
	HP Officejet 635 All-in-One	End of Support
	HP Officejet 700 All-in-One	End of Support
	HP Officejet 710 All-in-One	End of Support
	HP Officejet 7100 All-in-One	End of Support
	HP Officejet 7110 All-in-One	End of Support

	Model Name	Support Level
	HP Officejet 7110xi All-in-One	End of Support
	HP Officejet 7115 All-in-One	End of Support
	HP Officejet 7130 All-in-One	End of Support
	HP Officejet 7130xi All-in-One	End of Support
	HP Officejet 7135xi All-in-One	End of Support
	HP Officejet 7140xi All-in-One	End of Support
	HP Officejet 720 All-in-One	End of Support
	HP Officejet 7500 e910	End of Support
	HP Officejet All-in-One	End of Support
	HP Officejet g55 All-in-One	End of Support
	HP Officejet g55xi All-in-One	End of Support
	HP Officejet g85 All-in-One	End of Support
	HP Officejet g85xi All-in-One	End of Support
	HP Officejet g95 All-in-One	End of Support
	HP Officejet j3508 All-in-One	Partial
	HP Officejet j3608 All-in-One	Partial
	HP Officejet j3625 All-in-One	Partial
	HP Officejet j3635 All-in-One	Partial
	HP Officejet j3640 All-in-One	Partial
	HP Officejet j3650 All-in-One	Partial
	HP Officejet j3680 All-in-One	Partial
	HP Officejet j5505 All-in-One	End of Support
	HP Officejet j5508 All-in-One	End of Support
	HP Officejet j5510 All-in-One	End of Support
	HP Officejet j5510v All-in-One	End of Support
	HP Officejet j5510xi All-in-One	End of Support
	HP Officejet j5515 All-in-One	End of Support
	HP Officejet j5520 All-in-One	End of Support
	HP Officejet k60 All-in-One	End of Support
	HP Officejet k60xi All-in-One	End of Support
	HP Officejet k80xi All-in-One	End of Support
	HP Officejet Lx All-in-One	End of Support
	HP Officejet Pro 1150c All-in-One	End of Support
	HP Officejet Pro 1150cse All-in-One	End of Support
	HP Officejet Pro 1170c All-in-One	End of Support
	HP Officejet Pro 1170cse All-in-One	End of Support
	HP Officejet Pro 1170cxi All-in-One	End of Support
	HP Photosmart 475 Compact Photo Printer	End of Support
	HP Photosmart 475v Compact Photo Printer	End of Support
	HP Photosmart 475xi Compact Photo Printer	End of Support
	HP Photosmart 7150 Printer	End of Support
	HP Photosmart 7150 Series Printer	End of Support
	HP Photosmart 7150v Printer	End of Support
	HP Photosmart 7150w Printer	End of Support
	HP Photosmart 7260 Photo Printer	End of Support
	HP Photosmart 7260v Photo Printer	End of Support
	HP Photosmart 7260w Photo Printer	End of Support
	HP Photosmart 7268 Photo Printer	End of Support
	HP Photosmart 7350 Printer	End of Support
	HP Photosmart 7350 Series Printer	End of Support
	HP Photosmart 7350v Printer	End of Support
	HP Photosmart 7350w Printer	End of Support

	Model Name	Support Level
	HP Photosmart 7960gp Photo Printer	End of Support
	HP Photosmart 7960w Photo Printer	End of Support
	HP Photosmart a310 Compact Photo Printer	End of Support
	HP Photosmart a311 Compact Photo Printer	End of Support
	HP Photosmart a314 Compact Photo Printer	End of Support
	HP Photosmart a316 Compact Photo Printer	End of Support
	HP Photosmart a430 Compact Photo Printer	End of Support
	HP Photosmart a432 Compact Photo Printer	End of Support
	HP Photosmart a433 Compact Photo Printer	End of Support
	HP Photosmart a434 Compact Photo Printer	End of Support
	HP Photosmart a436 Compact Photo Printer	End of Support
	HP Photosmart a440 Compact Photo Printer	End of Support
	HP Photosmart a442 Compact Photo Printer	End of Support
	HP Photosmart a446 Compact Photo Printer	End of Support
	HP Photosmart d6160 Printer	End of Support
	HP Photosmart d6163 Printer	End of Support
	HP Photosmart d6168 Printer	End of Support
	HP Photosmart d7560 Printer	End of Support
	HP Photosmart p1000/1000 Printer	End of Support
	HP Photosmart p1000xi Printer	End of Support
	HP Photosmart p1100 Printer	End of Support
	HP Photosmart p1100xi Printer	End of Support
	HP Printer Scanner Copier 300	End of Support
	HP PSC 1110 All-in-One	Partial
	HP PSC 1110v All-in-One	Partial
	HP PSC 1118 All-in-One	Partial
	HP PSC 1200 All-in-One	Partial
	HP PSC 1205 All-in-One	Partial
	HP PSC 1209 All-in-One	Partial
	HP PSC 1210 All-in-One	Partial
	HP PSC 1210v All-in-One	Partial
	HP PSC 1210xi All-in-One	Partial
	HP PSC 1213 All-in-One	Partial
	HP PSC 1215 All-in-One	Partial
	HP PSC 1216 All-in-One	Partial
	HP PSC 1217 All-in-One	Partial
	HP PSC 1218 All-in-One	Partial
	HP PSC 1219 All-in-One	Partial
	HP PSC 1300 All-in-One	Partial
	HP PSC 1310 All-in-One	Partial
	HP PSC 1311 All-in-One	Partial
	HP PSC 1312 All-in-One	Partial
	HP PSC 1315 All-in-One	Partial
	HP PSC 1315s All-in-One	Partial
	HP PSC 1315v All-in-One	Partial
	HP PSC 1315xi All-in-One	Partial
	HP PSC 1317 All-in-One	Partial
	HP PSC 1318 All-in-One	Partial
	HP PSC 1340 All-in-One	Partial
	HP PSC 1345 All-in-One	Partial
	HP PSC 1350 All-in-One	Partial
	HP PSC 1350v All-in-One	Partial

	Model Name	Support Level
	HP PSC 1350xi All-in-One	Partial
	HP PSC 1355 All-in-One	Partial
	HP PSC 1401 All-in-One	Partial
	HP PSC 1402 All-in-One	Partial
	HP PSC 1403 All-in-One	Partial
	HP PSC 1406 All-in-One	Partial
	HP PSC 1408 All-in-One	Partial
	HP PSC 1410 All-in-One	Partial
	HP PSC 1410v All-in-One	Partial
	HP PSC 1410xi All-in-One	Partial
	HP PSC 1415 All-in-One	Partial
	HP PSC 1417 All-in-One	Partial
	HP PSC 2105 All-in-One	End of Support
	HP PSC 2108 All-in-One	End of Support
	HP PSC 2110 All-in-One	End of Support
	HP PSC 2110v All-in-One	End of Support
	HP PSC 2110xi All-in-One	End of Support
	HP PSC 2115 All-in-One	End of Support
	HP PSC 2150 All-in-One	End of Support
	HP PSC 2200 All-in-One	End of Support
	HP PSC 2210 All-in-One	End of Support
	HP PSC 2210v All-in-One	End of Support
	HP PSC 2210xi All-in-One	End of Support
	HP PSC 500 All-in-One	End of Support
	HP PSC 500xi All-in-One	End of Support
	HP PSC 720 All-in-One	End of Support
	HP PSC 750 All-in-One	End of Support
	HP PSC 750xi All-in-One	End of Support
	HP PSC 760 All-in-One	End of Support
	HP PSC 780 All-in-One	End of Support
	HP PSC 780xi All-in-One	End of Support
	HP PSC 900 All-in-One	End of Support
	HP PSC 950 All-in-One	End of Support
	HP PSC 950vr All-in-One	End of Support
	HP PSC 950xi All-in-One	End of Support
	HP Officejet Pro 1175c All-in-One	End of Support
	HP Officejet Pro 1175cse All-in-One	End of Support
	HP Officejet Pro 1175cxi All-in-One	End of Support
	HP Officejet Pro k550 Printer	End of Support
	HP Officejet Pro k550dtn Printer	End of Support
	HP Officejet Pro k550dtwn Printer	End of Support
	HP Officejet Pro k550xi Printer	End of Support
	HP Officejet Pro k850 Printer	End of Support
	HP Officejet Pro k850dn Printer	End of Support
	HP Officejet Pro I7300 Series All-in-One	End of Support
	HP Officejet Pro I7380 All-in-One	End of Support
	HP Officejet r40 All-in-One	End of Support
	HP Officejet r40xi All-in-One	End of Support
	HP Officejet r60 All-in-One	End of Support
	HP Officejet r80 All-in-One	End of Support
	HP Officejet r80xi All-in-One	End of Support
	HP Officejet v30 All-in-One	End of Support

	Model Name	Support Level
	HP Officejet v40 All-in-One	End of Support
	HP Officejet v40s All-in-One	End of Support
	HP Officejet v40xi All-in-One	End of Support
	HP Officejet v45 All-in-One	End of Support
	HP Photosmart 100 Printer	End of Support
	HP Photosmart 1115 Printer	End of Support
	HP Photosmart 1215 Printer	End of Support
	HP Photosmart 1215vm Printer	End of Support
	HP Photosmart 1218 Printer	End of Support
	HP Photosmart 1218xi Printer	End of Support
	HP Photosmart 1315 Printer	End of Support
	HP Photosmart 140 Compact Photo Printer	End of Support
	HP Photosmart 145 Compact Photo Printer	End of Support
	HP Photosmart 145v Compact Photo Printer	End of Support
	HP Photosmart 145xi Compact Photo Printer	End of Support
	HP Photosmart 148 Compact Photo Printer	End of Support
	HP Photosmart 230 Printer	End of Support
	HP Photosmart 230v Printer	End of Support
	HP Photosmart 230xi Printer	End of Support
	HP Photosmart 240 Compact Photo Printer	End of Support
	HP Photosmart 245 Compact Photo Printer	End of Support
	HP Photosmart 245v Compact Photo Printer	End of Support
	HP Photosmart 245xi Compact Photo Printer	End of Support
	HP Photosmart 330 Series Compact Photo Printer	End of Support
	HP Photosmart 335 Compact Photo Printer	End of Support
	HP Photosmart 335v Compact Photo Printer	End of Support
	HP Photosmart 335xi Compact Photo Printer	End of Support
	HP Photosmart 337 Compact Photo Printer	End of Support
	HP Photosmart 338 Compact Photo Printer	End of Support
	HP Photosmart 420 Compact Photo Printer	End of Support
	HP Photosmart 422 Compact Photo Printer	End of Support
	HP Photosmart 422v Compact Photo Printer	End of Support
	HP Photosmart 422xi Compact Photo Printer	End of Support
	HP Photosmart 425 Compact Photo Printer	End of Support
	HP Photosmart 425v Compact Photo Printer	End of Support
	HP Photosmart 428 Compact Photo Printer	End of Support
	HP Photosmart 428v Compact Photo Printer	End of Support